


DIAGRAM ELECTRIC EL6 with all security



n°4 = OUT OF BALANCE

Contact is closed if drum is too heavy before spin
 Contact is open if drum is normally

n°5 = WASHER MOTEUR

thermal contact installed on motor
 Contact is closed if moteur is normally
 Contact is open if motor is too hot

n°6 = WASHER DOOR

Contact is closed if door is closed
 Contact is open if door is open

n°7 = WASHER DOOR

Contact is closed if door is not closed (blocked)
 Contact is open if door is closed

